

इंटरनेट

मानक

Disclosure to Promote the Right To Information

Whereas the Parliament of India has set out to provide a practical regime of right to information for citizens to secure access to information under the control of public authorities, in order to promote transparency and accountability in the working of every public authority, and whereas the attached publication of the Bureau of Indian Standards is of particular interest to the public, particularly disadvantaged communities and those engaged in the pursuit of education and knowledge, the attached public safety standard is made available to promote the timely dissemination of this information in an accurate manner to the public.

“जानने का अधिकार, जीने का अधिकार”

Mazdoor Kisan Shakti Sangathan

“The Right to Information, The Right to Live”

“पुराने को छोड़ नये के तरफ”

Jawaharlal Nehru

“Step Out From the Old to the New”

IS 11720-1 (1986): Methods of Test for Synthetic Rubber, Part 1: Determination of Antioxidants [PCD 13: Rubber and Rubber Products]



“ज्ञान से एक नये भारत का निर्माण”

Satyanarayan Gangaram Pitroda

“Invent a New India Using Knowledge”



“ज्ञान एक ऐसा खजाना है जो कभी चुराया नहीं जा सकता है”

Bhartrhari—Nitiśatakam

“Knowledge is such a treasure which cannot be stolen”

BLANK PAGE



IS : 11720 (Part 1) - 1986
(Reaffirmed 1995)

Indian Standard

METHODS OF
TEST FOR SYNTHETIC RUBBER
PART 1 DETERMINATION OF ANTIOXIDANTS

[SR : 1]

(First Reprint APRIL 1998)

UDC 678.7 : 543.678.048

© *Copyright* 1986

BUREAU OF INDIAN STANDARDS
MANAK BHAVAN, 9 BAHADUR SHAH ZAFAR MARG
NEW DELHI 110002

Indian Standard

**METHODS OF
TEST FOR SYNTHETIC RUBBER
PART 1 DETERMINATION OF ANTIOXIDANTS
[SR : 1]**

Rubber Sectional Committee, PCDC 14

Chairman

SHRI LALIT MOHAN JAMNADAS

Representing

Cosmos India Rubber Works Pvt Ltd, Bombay

Vice-Chairman

SHRI S. B. GANGULY

Dunlop India Ltd, Calcutta

SHRI K. S. LOGANATHAN (*Alternate*)*Members*

SHRI SATISH ABRAHAM

Padinjarekara Agencies Ltd, Kottayam

SHRI O. P. AGARWAL

Transasia Carpets Ltd, Sikandrabad

SHRI J. N. JHA (*Alternate*)

SHRI A. K. BANDOPADHAYA

Ministry of Defence (DGI)

SHRI V. BHATTACHARYA (*Alternate*)

DR B. BANERJEE

Carbon and Chemicals India Ltd, Cochin

DR D. BANERJEE

Escon Consultants Pvt Ltd, Calcutta

DR P. S. BHARGAVA

Alkali and Chemical Corporation of India Ltd,
CalcuttaSHRI N. C. SAMAJDAR (*Alternate*)

SHRI J. CHATTERJEE

Andrew Yule & Co Ltd, Calcutta

SHRI A. K. BISWAS (*Alternate*)

SHRI P. K. CHATTERJEE

All India Rubber Industries Association, Bombay

DR S. N. CHAKRAVARTY (*Alternate*)

SHRI H. C. CHOPRA

Synthetics and Chemicals Ltd, Bombay

DR R. N. MEHROTRA (*Alternate*)

SHRI D. W. MCCRIRICK

Association of Planters of Kerala, Cochin

SHRI P. K. MENON (*Alternate*)

DR D. K. DAS

National Test House, Calcutta

SHRI A. GHOSH (*Alternate*)

SHRI P. B. C. DASTIDAR

Bata India Ltd, Calcutta

SHRI S. SARKAR (*Alternate*)

SHRI S. L. GANDHI

Ministry of Defence (R & D)

SHRI H. C. PERTI (*Alternate*)(*Continued on page 2*)© *Copyright* 1986

BUREAU OF INDIAN STANDARDS

This publication is protected under the *Indian Copyright Act* (XIV of 1957) and reproduction in whole or in part by any means except with written permission of the publisher shall be deemed to be an infringement of copyright under the said Act.

(Continued from page 1)

| <i>Members</i> | <i>Representing</i> |
|--|---|
| SHRI J. M. GARG | Directorate General of Technical Development, New Delhi |
| SHRI A. GEORGE JOHN | MRF Ltd, Madras |
| SHRI K. J. JOSEPH | Plantation Corporation of Kerala Ltd, Kottayam |
| SHRI K. T. VERGHESE (<i>Alternate</i>) | |
| SHRI G. R. KAVISHVAR | Indian Rubber Regenerating Co Ltd, Thane |
| SHRI P. S. VIRANI (<i>Alternate</i>) | |
| SHRI K. N. KOSHY | M. M. Rubber Co Ltd, Madras |
| SHRI N. SUBRAMANIAN (<i>Alternate</i>) | |
| SHRI P. K. MADHAVA MENON | Thirumbadi Rubber Ltd, Mookam |
| SHRI M. PUSHKARAKSHAN (<i>Alternate</i>) | |
| SHRI L. K. MATHUR | Modi Rubber Ltd, Modipuram |
| SHRI P. K. MENON | United Planters, Association of Southern India, Coonoor |
| SHRI E. B. UNNI (<i>Alternate</i>) | |
| DR W. MILLNS | Indian Rubber Manufacturers Research Association, Thane |
| SHRI N. B. FEGADE (<i>Alternate</i>) | |
| SHRI R. MURLEEDHARAN NAIR | Hindustan Latex Ltd, Trivandrum |
| SHRI R. R. PANDIT | Bayer (India) Ltd, Bombay |
| SHRI D. J. BHARUCHA (<i>Alternate</i>) | |
| SHRI S. A. PASHA | London Rubber Co (India) Ltd, Madras |
| SHRI R. KRISHNAN (<i>Alternate</i>) | |
| SHRI M. C. PAUL | Arakkunnam Cooperative Rubber Marketing Society Ltd, P.O. Arakkunnam |
| SHRI A. RAJAMANI | Automotive Tyre Manufacturers Association, New Delhi |
| SHRI A. GEORGE JOHN (<i>Alternate</i>) | |
| DR S. K. RAY | Tyre Corporation of India Ltd, Calcutta |
| SHRI S. B. SARKAR (<i>Alternate</i>) | |
| SHRI S. V. SARMA | Travancore Rubber & Tea Co Ltd, Trivandrum |
| SHRI C. S. KRISHNASWAMY (<i>Alternate</i>) | |
| SHRI SUNIL I. SHAH | Indian Petrochemicals Corporation Ltd, P. O. Petrochemicals, Vadodara |
| SHRI A. K. MALLIK (<i>Alternate</i>) | |
| SHRI RAJINDER SINGH | State Trading Corporation of India Ltd, Bombay |
| SHRI O. P. ARORA (<i>Alternate</i>) | |
| DR E. V. THOMAS | Rubber Research Institute of India, Kottayam; and Rubber Board, Kottayam |
| DR M. G. KUMARAN (<i>Alternate I</i>) | |
| DR N. M. MATHEW (<i>Alternate II</i>) | |
| SHRI M. S. SAXENA, Director (P & C) | Director General, ISI (<i>Ex-officio Member</i>) |

Secretary

SHRI DILEEP KUMAR
Assistant Director (P & C), ISI

(Continued on page 10)

Indian Standard

METHODS OF TEST FOR SYNTHETIC RUBBER

PART 1 DETERMINATION OF ANTIOXIDANTS

[SR : 1]

0. FOREWORD

0.1 This Indian Standard was adopted by the Indian Standards Institution on 28 March 1986, after the draft finalized by the Rubber Sectional Committee had been approved by the Petroleum, Coal and Related Products Division Council.

0.2 This standard is the first in the new SR (synthetic rubber) series for common methods of test which are applicable to all types of synthetic rubbers currently indigenously produced, namely, styrene-butadiene rubber (SBR), acrylonitrile butadiene rubber (NBR) and polybutadiene rubber (BR). Other unified test methods similarly applicable to these synthetic rubbers will form the subsequent parts of this (SR) series.

0.3 Method of test for determination of antioxidants in styrene-butadiene rubber (SBR) had been originally covered in SBR : 6 of IS : 4518 (Part 1)-1967*. Later a method of test for determination of antioxidants in polybutadiene rubbers (BR) was issued as draft Indian Standard under document No. PCDC 14 (385). Methods of test for polybutadiene rubbers: Part 3 Determination of antioxidants.

0.3.1 While conceiving the idea of common methods of test for synthetic rubber under SR (synthetic rubber) series, the Committee took cognizance of the fact that the present methods for determination of antioxidants in SBR and BR could be unified and a method of test for determination of antioxidants in all types of synthetic rubbers evolved and published under SR series.

0.4 Determination of antioxidants is important as it provides information to the consumer which helps him in compounding techniques.

*Methods of tests for styrene-butadiene rubbers (SBR): Part 1 Determination of volatile matter, total ash, organic acid, soap, antioxidants, bound styrene and mooney viscosity.

IS : 11720 (Part 1) - 1986

0.5 In the preparation of this standard considerable assistance has been derived from ASTM D 1416-1983 Standard methods for rubber from synthetic sources—Chemical analysis, issued by American Society for Testing and Materials, USA.

0.6 For the purpose of deciding whether a particular requirement of this standard is complied with, the final value, observed or calculated, expressing the result of a test or analysis, shall be rounded off in accordance with IS : 2-1960*. The number of significant places retained in the rounded off value should be the same as that of the specified value in this standard

1. SCOPE

1.1 This standard prescribes a method for the quantitative estimation of a known antioxidant (amine or phenolic) in synthetic rubber. The antioxidant should have a distinct UV absorption band.

2. QUALITY OF REAGENTS

2.1 Unless specified otherwise, pure chemicals and distilled water (see IS : 1070-1977†) shall be employed in tests.

NOTE — 'Pure chemicals' shall mean chemicals that do not contain impurities which affect the result of analysis.

3. OUTLINE OF THE METHOD

3.1 A representative sample of the polymer is extracted into ethanol-toluene azeotrope (ETA) solvent. The absorbance of a diluted portion of the extract with or without further chemical treatment, is measured by an ultra-violet spectrophotometer, from which the antioxidant content is calculated.

4. APPARATUS

4.1 Spectrophotometer — A suitable UV spectrophotometer, with wavelength accurate to ± 0.1 nm and absorbance precision of ± 0.005 , and capable of operating in the 200-400 nm region shall be used. The type of recorder to be used is optional.

4.2 Mechanical Shaker — Any wrist-action shaker.

4.3 Analytical Balance — Accuracy 0.000 1 g.

4.4 Volumetric Flasks — 50, 100, 250-ml into ground-glass stoppers.

4.5 Quartz-Cell — 1 cm cells (matching).

*Rules for rounding off numerical values (revised).

†Specification for water for general laboratory use (second revision).

5. REAGENTS

5.1 Spectroscopic Solvent — Methylcyclohexane and ethanol (see Table 1) having an optical transmission greater than 90 percent and toluene with transmission greater than 30 percent at the wavelength specified for the antioxidant to be determined.

TABLE 1 SOLVENTS AND TEST CONDITIONS FOR ANTIOXIDANT DETERMINATION

| ANTIOXIDANT | SPECTROSCOPIC SOLVENT | WAVELENGTH (nm) | TYPICAL BACKGROUND CORRECTION PER GRAM OF SBR PER 250 ml | |
|--|--|-------------------|--|-----------|
| | | | Hot Type | Cold Type |
| Phenylbetanaphthylamine (PBNA) | Toluene | 309 ± 1 | 0.085 | 0.280 |
| | Methylcyclohexane | 309 ± 1 | 0.115 | 0.325 |
| Acetone-diphenylamine condensation product (BLE) | 85 percent methylcyclohexane and 15 percent ethanol* | 288 ± 1 | 0.235 | 0.495 |
| Mixed alkylated diphenylamines | 85 percent methylcyclohexane and 15 percent ethanol | 288 ± 1 | 0.225 | 0.495 |
| | | 288 ± 1 | 0.235 | 0.495 |

*Use anhydrous ethanol.

5.2 Ethanol — Anhydrous grade.

5.3 Ethyl Alcohol-Toluene Azeotrope (ETA) — Mix 70 volumes of ethanol and 30 volumes of toluene; reflux for 4 hours over CaO and distil. Collect the distillate, discarding first and last fraction keeping only that distillate, coming over within a range of 1°C.

5.4 Alcoholic KOH — 14 g of potassium hydroxide (KOH) is ground with successive 50 ml portions of anhydrous ethanol till complete dissolution, then dilute to 400 ml and filter quickly. Keep in sealed dark bottles overnight before use.

NOTE — Needed when the antioxidant to be determined is mixed alkylated phenols.

5.5 Ethanol-Phenol (EP) Solution — Dissolve about 0.300 g of phenolic antioxidant in one litre of ethanol.

6. PROCEDURE

6.1 Prepare ETA extract following the procedure given below.

6.1.1 Take a portion of rubber at least 250 g prepared according to **3.1** of IS : 4518 (Part 1)-1967* and sheet it out on a laboratory mill by pressing it, not more than twice, between the cold rolls set at 0.25 mm distance. Weigh accurately two pieces of about 10 g of sheeted rubber. Place in an oven at 100° to 105°C for at least one hour and until the loss in weight on successive weighings at half-hour intervals is less than 1 mg. Pass through mill and get thin (less than 0.5 mm thick) sheet out. Cut the sheet into small strips of not wider than 10 mm and not longer than 50 mm.

6.1.2 Add 100 ml of ethanol-toluene azeotrope to the wide mouth flask. Accurately weigh 6 g of the strips. Add each strip of the weighed sample separately to the flask, swirling the flask after each addition so that each strip is thoroughly wetted with solvent. To prevent the strips from sticking to the flask, place a filter paper at the bottom of the flask. Use wire gauze or asbestos mat between the flask and the hot plate. Reflux the contents for one hour. Decant the liquid into the volumetric flask. Add a second 100-ml portion of the ETA to the rubber sample and reflux again for one hour. Decant liquid into the volumetric flask. • Rinse the sample with successive 10 ml portions of fresh ETA and add these rinsings to the volumetric flask. Cool the ETA solution to room temperature and add enough fresh ETA to bring the volume to the 250-ml mark. Mix the contents thoroughly.

6.2 Method for Amine Antioxidants — Pipette accurately 2 ml of the ETA extract into a 100-ml volumetric flask, and make-up the 100 ml mark with spectroscopic solvent (see Table 1).

6.2.1 In case absorptivity (α) of the antioxidant is unknown, then determine α in the following manner and prepare a table for amine antioxidants for ready reference in future. (If α can be easily referred, the procedure in **6.2.1** can be eliminated.) Obtain two or more representative samples of the antioxidant which shall, in the case of acetone diphenylamine reaction product and mixed alkylated diphenylamines, be heated to a temperature at which they can easily flow. Thoroughly mix the antioxidant and prepare a standard solution of it in the proper spectroscopic solvent. The convenient strengths of the solutions are as follows:

| | |
|----------------------------------|----------|
| a) Phenyl- β naphthylamine | 0.24 g/l |
| b) Acetone — diphenylamine | 0.24 g/l |
| c) Mixed alkylated diphenylamine | 0.32 g/l |

*Methods of test for styrene-butadiene rubbers (SBR): Part 1 Determination of volatile matter, total ash, organic acid, soap, antioxidant, bound styrene and mooney viscosity.

The strength (c) shall be accurate to ± 0.0005 percent. Carefully measure three 3.00 ml aliquots (d) of this solution into 100-ml volumetric flasks and make up the volume with the spectroscopic solvents. Determine absorbance of the solutions at appropriate wavelength (λ) (see Table 1) into the pure solvent kept in the reference beam. Make several measurements on each diluted aliquot until a reproducible absorbance result (A_s) is obtained.

6.2.2 Measure the absorbance (A_t) of the test solutions in matched 1 cm cells at the specified wavelength λ , keeping mixed solvent in the reference beam. The mixed solvent is made by adding ETA and the spectroscopic solvent in the same ratio as that used in the solution containing the ETA extract of the rubber.

NOTE — For both 6.2.1 and 6.2.2, the absorbance observed shall be between 0.4 and 1.0. If not, use a different aliquot of the ETA extract so as to bring the absorbance within the desired range, being sure to use the same proportion of ETA in the beam as in the sample.

6.3 Method for Phenolic Antioxidants (Alkylated and other Substituted Phenols, Phenolic Esters, etc)

NOTE — Spectrophotometric measurements shall be made preferably the same day as the standards and the test-sample extract is prepared.

6.3.1 Prepare basic and neutral solutions in six separate 50-ml volumetric flasks as in Table 2.

TABLE 2 VOLUME IN MILLILITRES OF VARIOUS SOLVENTS FOR MAKING UP 50-ml OF BASIC AND NEUTRAL SOLUTIONS

| Sl. No. | SOLUTION | EP SOLUTION | ETA SOLVENT | 0.5 M KOH SOLUTION | ETA EXTRACT OF TEST SAMPLE | ETHANOL (TO 50-ml MARK) |
|---------|-----------------------|-------------|-------------|--------------------|----------------------------|---------------------------|
| (1) | (2) | (3) | (4) | (5) | (6) | (7) |
| i) | Basic standard(BS) | 5 | 5 | 10 | — | 30 |
| ii) | Basic reference(BR) | — | 5 | 10 | — | 35 |
| iii) | Basic test (BT) | — | — | 10 | 5 | 35 |
| iv) | Neutral standard(NS) | 5 | 5 | — | — | 40 |
| v) | Neutral reference(NR) | 0 | 5 | — | — | 45 |
| vi) | Neutral test (NT) | — | — | — | 5 | 45 |

6.3.2 Using matched 1 cm cells, absorbance (A) of the solution are measured at 301 nm, keeping the corresponding reference solution in the reference beam.

NOTE — 301 nm should be used for mixed alkylated phenols antioxidant. For other phenols or phenolic esters, the quantities of standard material and of sample and the value of the wavelength are to be adjusted.

7. CALCULATION

7.1 For Amine Antioxidants

7.1.1 Calculate the absorptivity as follows:

$$\alpha = \frac{100 A_s}{c d}$$

where

A_s = absorbance of standard solution,

c = concentration of the antioxidant in the standard as g/l;
and

d = volume of aliquot in ml taken from the standard solution.

7.1.1.1 For SBR, correct the absorbance of a standard solution as follows:

$$A_s = [\text{Observed } A_s - \text{background correction factor}]$$

7.1.2 Calculate the percentage antioxidant as follows:

$$\text{Amine antioxidant, percent by mass} = \frac{2500 A_t}{m V \alpha}$$

where

A_t = absorbance of solution,

V = volume (ml) of extract dissolved in spectroscopic solvent,

m = mass of rubber (g) of original sample extracted, and

α = absorptivity (see 7.1.1).

7.2 For Phenolic Antioxidants

7.2.1 Calculate absorptivity difference (Δ_s) as follows:

$$\text{Absorptivity difference (} \Delta_s \text{)} = \frac{A_{BS} - A_{NS}}{0.030}$$

where

A_{BS} = absorbance of basic standard solution; and

A_{NS} = absorbance of neutral standard solution.

7.2.2 Calculate the percentage antioxidant as follows:

$$\text{Mixed alkylated phenolic antioxidant concentration, percent by mass} = \left[\frac{A_{\text{BT}} - A_{\text{NT}}}{\Delta_{\text{s}}} \times 2.4 \right] \times 100$$

where

A_{BT} = absorbance of basic test solution,

A_{NT} = absorbance of neutral test solution, and

Δ_{s} = absorptivity difference (see 7.2.1).

IS : 11720 (Part 1) - 1986*(Continued from page 2)***Methods of Testing Subcommittee, PCDC 14 : 1**

| <i>Convener</i> | <i>Representing</i> |
|--|---|
| DR S. N. CHAKRAVARTY | Modi Rubber Ltd, Modipuram |
| <i>Members</i> | |
| SHRI S. K. MUSTAFI (<i>Alternate</i> to Dr S. N. Chakravarty) | |
| SHRI SATISH ABRAHAM | Padinjarekara Agencies Ltd, Kottayam |
| SHRI P. S. BALASUBRAMANIAM | L. G. Balakrishnan & Bros Ltd, Coimbatore |
| SHRI S. KUMAR (<i>Alternate</i>) | |
| SHRI A. N. BHATTACHARYA | Union Commercial & Industrial Co Pvt Ltd, Calcutta |
| SHRI B. PANJA (<i>Alternate</i>) | |
| SHRI P. K. CHATTERJEE | Bayer (India) Ltd, Bombay |
| SHRI D. J. BHARUCHA (<i>Alternate</i>) | |
| SHRI J. CHATTERJEE | Andrew Yule & Co Ltd, Calcutta |
| SHRI A. K. BISWAS (<i>Alternate</i>) | |
| SHRI H. C. CHOOPRA | Synthetics & Chemicals Ltd, Bombay |
| DR R. N. MEHROTRA (<i>Alternate</i>) | |
| SHRI K. R. GARG | Ministry of Defence (DGI) |
| SHRI P. L. NAG (<i>Alternate</i>) | |
| SHRI J. M. GARG | Directorate General of Technical Development, New Delhi |
| SHRI C. S. INAMDAR | Polyolefins Industries Ltd, Bombay |
| SHRI V. K. SUD (<i>Alternate</i>) | |
| SHRI A. GEORGE JOHN | MRF Ltd, Madras |
| SHRI G. R. KAVISHVAR | Indian Rubber Regenerating Co Ltd, Bombay |
| SHRI P. S. VIRANI (<i>Alternate</i>) | |
| SHRI P. L. KINARIWALA | Cosmos India Rubber Works Pvt Ltd, Bombay |
| SHRI S. N. GHADGE (<i>Alternate</i>) | |
| SHRI K. S. LOGANATHAN | Dunlop India Ltd, Calcutta |
| DR S. CHATTOPADHYAY (<i>Alternate</i>) | |
| SHRI P. K. MADHAVA MENON | Thirumbadi Rubber Co Ltd, Mokkalam |
| SHRI A. K. MALLIK | Indian Petrochemicals Corporation Ltd, P.O. petrochemicals, Vadodara |
| DR Y. N. SHARMA (<i>Alternate</i>) | |
| DR W. MILLNS | Indian Rubber Manufacturers' Research Association, Thane |
| SHRI ASOK MITRA | Tyre Corporation of India Ltd, Calcutta |
| DR S. K. RAY (<i>Alternate</i>) | |
| SHRI P. K. PAIN | National Test House, Calcutta |
| SHRI S. V. SARMA | Travancore Rubber & Tea Co Ltd, Trivandrum |
| SHRI C. S. KRISHNASWAMY (<i>Alternate</i>) | |
| SHRI E. V. THOMAS | Rubber Board, Kottayam |
| DR N. M. MATHEW (<i>Alternate</i>) | |

BUREAU OF INDIAN STANDARDS

Headquarters:

Manak Bhavan, 9 Bahadur Shah Zafar Marg, NEW DELHI 110002

Telephones: 323 0131, 323 3375, 323 9402

Fax : 91 11 3234062, 91 11 3239399, 91 11 3239382

Telegrams : Manaksanstha

(Common to all Offices)

Central Laboratory:

Plot No. 20/9, Site IV, Sahibabad Industrial Area, SAHIBABAD 201010

Telephone

8-77 00 32

Regional Offices:

Central : Manak Bhavan, 9 Bahadur Shah Zafar Marg, NEW DELHI 110002 323 76 17

*Eastern : 1/14 CIT Scheme VII M, V.I.P. Road, Maniktola, CALCUTTA 700054 337 86 62

Northern : SCO 335-336, Sector 34-A, CHANDIGARH 160022 60 38 43

Southern : C.I.T. Campus, IV Cross Road, CHENNAI 600113 235 23 15

†Western : Manakalaya, E9 Behind Marol Telephone Exchange, Andheri (East),
MUMBAI 400093 832 92 95

Branch Offices:

'Pushpak', Nurmohamed Shaikh Marg, Khanpur, AHMEDABAD 380001 550 13 48

‡Peenya Industrial Area, 1st Stage, Bangalore - Tumkur Road,
BANGALORE 560058 839 49 55

Gangotri Complex, 5th Floor, Bhadbhada Road, T. T. Nagar, BHOPAL 462003 55 40 21

Plot No. 62-63, Unit VI, Ganga Nagar, BHUBANESHWAR 751001 40 36 27

Kalaikathir Buildings, 670 Avinashi Road, COIMBATORE 641037 21 01 41

Plot No. 43, Sector 16 A, Mathura Road, FARIDABAD 121001 8-28 88 01

Savitri Complex, 116 G. T. Road, GHAZIABAD 201001 8-71 19 96

53/5 Ward No. 29, R. G. Barua Road, 5th By-lane, GUWAHATI 781003 54 11 37

5-8-58C, L. N. Gupta Marg, Nampally Station Road, HYDERABAD 500001 20 10 83

E-52, Chitaranjan Marg, C-Scheme, JAIPUR 302001 37 29 25

117/418 B, Sarvodaya Nagar, KANPUR 208005 21 68 76

Seth Bhawan, 2nd Floor, Behind Leela Cinema, Naval Kishore Road,
LUCKNOW 226001 23 89 23

Patliputra Industrial Estate, PATNA 800013 26 23 05

T. C. No. 14/1421, University P. O. Palayam,
THIRUVANANTHAPURAM 695034 6 21 17

NIT Building, Second Floor, Gokulpat Market, NAGPUR 440010 52 51 71

Institution of Engineers (India) Building, 1332 Shivaji Nagar, PUNE 411005 32 36 35

*Sales Office is at 5 Chowringhee Approach, P. O. Princep Street,
CALCUTTA 700072 27 10 85

†Sales Office is at Novelty Chambers, Grant Road, MUMBAI 400007 309 65 28

‡Sales Office is at 'F' Block, Unity Building, Narashimaraja Square,
BANGALORE 560002 222 39 71